






➤ O. Hehner's method:

- ❖ Temporary Hardness: Acid-base titration is performed before and after boiling the hard water






Permanent Hardness: Chloride and sulphates of Ca and Mg are removed as insoluble CaCO_3 and MgCO_3 by boiling the hard water with excess Na_2CO_3 . Acid-base titration is performed before and after removal



➤ Soap titration method:

Hardness is estimated by adding a soap solution of known strength to a sample water solution until a permanent lather is formed after shaking






Estimation of hardness of water: EDTA method

➤ Water hardness can be readily determined by **complexometric titration** with the chelating agent EDTA




➤ EDTA is **ethylene diamine tetraacetic acid**.

➤ EDTA solution is colorless




➤ Corresponding disodium salt is used for the hardness estimation, as this salt forms very strong and stable complex with Ca^{2+} and Mg^{2+} .

❑ Initially, Ca^{2+} and Mg^{2+} or the are treated with Eriochrome black T (EBT) indicator using ammonia buffer (to maintain pH between 9-10) to get an unstable $\text{Ca}^{2+}/\text{Mg}^{2+}$ complex which imparts **wine-red colour** to the solution




EDTA method

- On addition of EDTA, EBT gets replaced by EDTA since EDTA forms a stronger complex with the metal ions



Ca²⁺ / Mg²⁺ - EBT complex

Wine red




Ca²⁺/Mg²⁺ – EDTA complex (colorless)

+ **EBT**
Steel blue



Overall process



- A 100 ml sample of water require 15 ml of 0.02 M EDTA for titration using EBT as indicator. Calculate the total hardness.
- [Ans.: Total=300ppm]
- (Hint:1000 mL 1MEDTA \equiv 1000 mL 1M CaCO_3 = 100 g of CaCO_3)